


## PRESTEX)

## Forged brass full way gate valve. BS 5154 PN20 Series B.



Size	Pattern No.	Pack 1 Qty	Pack 2 Qty	Code	Barcode	Price (£) ex VAT	Discontinued	Date Discontinued
3/8	1068	0	0	203006	5022050289605	POA	Discontinued	31/10/2004
1/2	1068	10	0	203007	5013866014895	£19.35		
3/4	1068	10	0	203008	5013866014901	£23.88		
1	1068	5	0	203009	5013866014918	£35.94		
1.1/4	1068	5 0		203010	5013866014925	£54.09		
1.1/2	1068	068 2 0		203011	5013866014932	£77.89		
2	1068	2	0	203012	5013866014949	£107.75		
2.1/2	1068	1	0	203013	5013866004292	£176.37		
3	1068	1	0	203014	5013866004308	£256.56		
4	1068	1	0	203015	5013866004315	£371.37		
1/2	1068 AT	10	0	203027	5022050233929	£19.35		
3/4	1068 AT	10	0	203028	5022050233967	£23.88		
1	1068 AT	5	0	203029	5022050234001	£35.94		
1.1/4	1068 AT	5	0	203030	5022050234049	£54.09		
1.1/2	1068 AT	2	0	203031	5022050234087	£77.89		
2	1068 AT	2	0	203032	5022050234124	£107.75		
2.1/2	1068 AT	1	0	203033	5022050233431	£176.37		
3	1068 AT	1	0	203034	5022050233493	£256.56		
4	1068 AT	1	0	203035	5022050233554	£371.37		
1/4	1068 PT	10		203045	5013866014956	POA	Discontinued	31/10/2004
3/8	1068 PT	10		203046	5013866014963	POA	Discontinued	31/10/2004
1/2	1068 PT	10	0	203047	5013866014970	£19.35		
3/4	1068 PT	10	0	203048	5013866014987	£23.88		
1			0	203049	5013866014994	£35.94		
1.1/4			203050	5013866015007	£54.09			
1.1/2			203051	5013866015014	£77.89			
2	1068 PT	2	0	203052	5013866015021	£107.75		
2.1/2	1068 PT	1	0	203053	5013866004407	£176.37		
3	1068 PT	1	0	203054	5013866004414 £256.56			
4	1068 PT	1		203055	5013866004421	POA	Discontinued	31/10/2004



203006       3/8 1068 BRASS GATE VALVE       43       85       0.22         203007       1/2 1068 BRASS GATE VALVE       52       85       0.32         203008       3/4 1068 BRASS GATE VALVE       56       95       0.46         203009       1 1068 BRASS GATE VALVE       65       110       0.69         203010       1.1/4 1068 BRASS GATE VALVE       73       125       1.03         203011       1.1/2 1068 BRASS GATE VALVE       76       145       1.40         203012       2 1068 BRASS GATE VALVE       90       170       2.28         203013       2.1/2 1068 BRASS GATE VALVE       102       205       3.68         203014       3 1068 BRASS GATE VALVE       114       240       5.42         203015       4 1068 BRASS GATE VALVE       134       290       10.59         203027       1/2 1068 AT BRASS GATE VALVE       52       85       0.32         203028       3/4 1068 AT BRASS GATE VALVE       56       95       0.46         203030       1.1/4 1068 AT BRASS GATE VALVE       73       125       1.03         203031       1.1/2 1068 AT BRASS GATE VALVE       73       125       1.03	Code	Description	Α	В	Kg
203008       3/4 1068 BRASS GATE VALVE       56       95       0.46         203009       1 1068 BRASS GATE VALVE       65       110       0.69         203010       1.1/4 1068 BRASS GATE VALVE       73       125       1.03         203011       1.1/2 1068 BRASS GATE VALVE       76       145       1.40         203012       2 1068 BRASS GATE VALVE       90       170       2.28         203013       2.1/2 1068 BRASS GATE VALVE       102       205       3.68         203014       3 1068 BRASS GATE VALVE       114       240       5.42         203015       4 1068 BRASS GATE VALVE       134       290       10.59         203027       1/2 1068 AT BRASS GATE VALVE       52       85       0.32         203028       3/4 1068 AT BRASS GATE VALVE       56       95       0.46         203029       1 1068 AT BRASS GATE VALVE       65       110       0.69         203030       1.1/4 1068 AT BRASS GATE VALVE       73       125       1.03	203006	3/8 1068 BRASS GATE VALVE	43	85	0.22
203009       1 1068 BRASS GATE VALVE       65       110       0.69         203010       1.1/4 1068 BRASS GATE VALVE       73       125       1.03         203011       1.1/2 1068 BRASS GATE VALVE       76       145       1.40         203012       2 1068 BRASS GATE VALVE       90       170       2.28         203013       2.1/2 1068 BRASS GATE VALVE       102       205       3.68         203014       3 1068 BRASS GATE VALVE       114       240       5.42         203015       4 1068 BRASS GATE VALVE       134       290       10.59         203027       1/2 1068 AT BRASS GATE VALVE       52       85       0.32         203028       3/4 1068 AT BRASS GATE VALVE       56       95       0.46         203029       1 1068 AT BRASS GATE VALVE       65       110       0.69         203030       1.1/4 1068 AT BRASS GATE VALVE       73       125       1.03	203007	1/2 1068 BRASS GATE VALVE	52	85	0.32
203010       1.1/4 1068 BRASS GATE VALVE       73       125       1.03         203011       1.1/2 1068 BRASS GATE VALVE       76       145       1.40         203012       2 1068 BRASS GATE VALVE       90       170       2.28         203013       2.1/2 1068 BRASS GATE VALVE       102       205       3.68         203014       3 1068 BRASS GATE VALVE       114       240       5.42         203015       4 1068 BRASS GATE VALVE       134       290       10.59         203027       1/2 1068 AT BRASS GATE VALVE       52       85       0.32         203028       3/4 1068 AT BRASS GATE VALVE       56       95       0.46         203029       1 1068 AT BRASS GATE VALVE       65       110       0.69         203030       1.1/4 1068 AT BRASS GATE VALVE       73       125       1.03	203008	3/4 1068 BRASS GATE VALVE	56	95	0.46
203011       1.1/2 1068 BRASS GATE VALVE       76       145       1.40         203012       2 1068 BRASS GATE VALVE       90       170       2.28         203013       2.1/2 1068 BRASS GATE VALVE       102       205       3.68         203014       3 1068 BRASS GATE VALVE       114       240       5.42         203015       4 1068 BRASS GATE VALVE       134       290       10.59         203027       1/2 1068 AT BRASS GATE VALVE       52       85       0.32         203028       3/4 1068 AT BRASS GATE VALVE       56       95       0.46         203029       1 1068 AT BRASS GATE VALVE       65       110       0.69         203030       1.1/4 1068 AT BRASS GATE VALVE       73       125       1.03	203009	1 1068 BRASS GATE VALVE	65	110	0.69
203012       2 1068 BRASS GATE VALVE       90       170       2.28         203013       2.1/2 1068 BRASS GATE VALVE       102       205       3.68         203014       3 1068 BRASS GATE VALVE       114       240       5.42         203015       4 1068 BRASS GATE VALVE       134       290       10.59         203027       1/2 1068 AT BRASS GATE VALVE       52       85       0.32         203028       3/4 1068 AT BRASS GATE VALVE       56       95       0.46         203029       1 1068 AT BRASS GATE VALVE       65       110       0.69         203030       1.1/4 1068 AT BRASS GATE VALVE       73       125       1.03	203010	1.1/4 1068 BRASS GATE VALVE	73	125	1.03
203013       2.1/2 1068 BRASS GATE VALVE       102       205       3.68         203014       3 1068 BRASS GATE VALVE       114       240       5.42         203015       4 1068 BRASS GATE VALVE       134       290       10.59         203027       1/2 1068 AT BRASS GATE VALVE       52       85       0.32         203028       3/4 1068 AT BRASS GATE VALVE       56       95       0.46         203029       1 1068 AT BRASS GATE VALVE       65       110       0.69         203030       1.1/4 1068 AT BRASS GATE VALVE       73       125       1.03	203011	1.1/2 1068 BRASS GATE VALVE	76	145	1.40
203014       3 1068 BRASS GATE VALVE       114       240       5.42         203015       4 1068 BRASS GATE VALVE       134       290       10.59         203027       1/2 1068 AT BRASS GATE VALVE       52       85       0.32         203028       3/4 1068 AT BRASS GATE VALVE       56       95       0.46         203029       1 1068 AT BRASS GATE VALVE       65       110       0.69         203030       1.1/4 1068 AT BRASS GATE VALVE       73       125       1.03	203012	2 1068 BRASS GATE VALVE	90	170	2.28
203015       4 1068 BRASS GATE VALVE       134       290       10.59         203027       1/2 1068 AT BRASS GATE VALVE       52       85       0.32         203028       3/4 1068 AT BRASS GATE VALVE       56       95       0.46         203029       1 1068 AT BRASS GATE VALVE       65       110       0.69         203030       1.1/4 1068 AT BRASS GATE VALVE       73       125       1.03	203013	2.1/2 1068 BRASS GATE VALVE	102	205	3.68
203027       1/2 1068 AT BRASS GATE VALVE       52       85       0.32         203028       3/4 1068 AT BRASS GATE VALVE       56       95       0.46         203029       1 1068 AT BRASS GATE VALVE       65       110       0.69         203030       1.1/4 1068 AT BRASS GATE VALVE       73       125       1.03	203014	3 1068 BRASS GATE VALVE	114	240	5.42
203028       3/4 1068 AT BRASS GATE VALVE       56       95       0.46         203029       1 1068 AT BRASS GATE VALVE       65       110       0.69         203030       1.1/4 1068 AT BRASS GATE VALVE       73       125       1.03	203015	4 1068 BRASS GATE VALVE	134	290	10.59
203029       1 1068 AT BRASS GATE VALVE       65       110       0.69         203030       1.1/4 1068 AT BRASS GATE VALVE       73       125       1.03	203027	1/2 1068 AT BRASS GATE VALVE	52	85	0.32
203030 1.1/4 1068 AT BRASS GATE VALVE 73 125 1.03	203028	3/4 1068 AT BRASS GATE VALVE	56	95	0.46
	203029	1 1068 AT BRASS GATE VALVE	65	110	0.69
203031 1 1/2 1068 AT RPASS GATE VALVE 76 445 4 40	203030	1.1/4 1068 AT BRASS GATE VALVE	73	125	1.03
200001 1.172 1000 AT BIAGO GATE VALVE 70 145 1.40	203031	1.1/2 1068 AT BRASS GATE VALVE	76	145	1.40

203032	2 1068 AT BRASS GATE VALVE	90	170	2.28
203033	2.1/2 1068 AT BRASS GATE VALVE	102	205	3.68
203034	3 1068 AT BRASS GATE VALVE	114	240	5.42
203035	4 1068 AT BRASS GATE VALVE	134	290	10.59
203045	1/4 1068 PT BRASS GATE VALVE	43	85	60
203046	3/8 1068 PT BRASS GATE VALVE	43	85	60
203047	1/2 1068 PT BRASS GATE VALVE	52	85	0.32
203048	3/4 1068 PT BRASS GATEVALVE	56	95	0.46
203049	1 1068 PT BRASS GATE VALVE	65	110	0.69
203050	1.1/4 1068 PT BRASS GATE VALVE	73	125	1.03
203051	1.1/2 1068 PT BRASS GATE VALVE	76	145	1.40
203052	2 1068 PT BRASS GATE VALVE	90	170	2.28
203053	2.1/2 1068 PT BRASS GATE VALVE	102	205	3.68
203054	3 1068 PT BRASS GATE VALVE	114	240	5.42
203055	4 1068 PT BRASS GATE VALVE	134	290	155
Pegler Yorkshire	reserve the right to change specifications			

### Valves and Fittings

### Pegler Yorkshire Customcare 5 Year Guarantee - Terms and Conditions

Products are subject to a 5 year guarantee that is between Pegler Yorkshire and the final purchaser of the product.

The guarantee is subject to proof of purchase being supplied.

This guarantee does not affect any statutory rights the consumer may have in law.

The guarantee covers manufacturing or material defects and does not cover parts subject to normal wear and tear.

This product range has been designed for the use of homeowners, domestic and commercial applications and therefore the guarantee is subject to the product being properly selected for their intended service conditions.

The guarantee is not applicable where the product is fitted contrary to the conditions in the fitting instructions.

This is reinforced where valves are covered by the European Pressure Equipment Directive (PED97/23/EC) where Installation, Operating and Maintenance Instructions are supplied with each product and/or carton.

Provided it is installed correctly and receives adequate preventative maintenance it should give years of trouble –free service.

Abusive behaviour and accidental damage to the product are not covered by this guarantee.

The extent of this liability is limited to the cost of the replacement of the defective item and not to fitting or consequential damages.





Description	Minimum Operating Pressure (bar)	Maximum Cold Working Pressure (bar)	Maximum Hot Working Pressure (bar)
1068 Forged Brass Full Bore Gate Valve	No Minimum Operating Pressure	20.0 bar at temperatures up to 100oC	9 bar at temperatures up to 180oC

### Care

No regular aesthetic care is required for this product

## Maintenance

A regular maintenance program is the most efficient method of ensuring longer term operational efficiency of the selected valve. Such a program would need to include a risk assessment and a planned procedure of how the maintenance will be carried out. The possibility of operational limits being exceeded and the potential hazards ensuring must be considered as part of this assessment. This should be implemented to include visual checks on the valve's condition and any development of unforeseen conditions, which could lead to failure. The correct fitting tools and equipment should be used for valve maintenance work. Separate means of draining the pipe work must be provided when carrying out any maintenance to valves. Where there may be any system debris this could be collected and /or filtered by installation of the appropriate protective device.

For further help please contact your local engineer.

If your product is under warranty please contact the Service Support Team on: 0800 1560050


## Regulations

## THE PRESSURE EQUIPMENT DIRECTIVE 97/23/EC and CE MARKING

The Pressure Equipment Regulations 1999 (SI 1999/2001) have now been introduced into United Kingdom

Valves with a maximum allowable pressure greater than 0.5 bar are covered by these new Regulations. Valves are categorised according to their maximum working pressure, size and rising level of hazard. The level of hazard varies according to the fluid being carried. Fluids are classified as Group 1, dangerous fluids or Group 2, all other fluids including steam. The Categories designated are SEP (sound engineering practice). Valves up to and including 25mm (1") are designated SEP regardless of the fluid group. Those identified as having increased hazard are Categorised as, I, II, III or IV. All valves designated as SEP do not bear the CE mark nor require a Declaration of Conformity. Categories I, II, III or IV carry the CE mark and require a Declaration of Conformity. Valves classified from the piping chart would not be included in Category IV.

Number	Component	Material
1	Body	Forged Brass
2	Bonnet	Forged Brass
3	Stem	Brass Bar
4	Wedge	Forged Brass
5	Stem Ring	Brass Bar
6	Gland	Brass Bar
7	Gland Nut	Brass Bar
8	Handwheel	Aluminium
9	Handwheel Nut	Brass Bar
10	Gland Packing	PTFE
11	Rating Disc	Aluminium



		1				
Spare Key	Description	Code	Barcode	Date From	Date To	Price (£) ex VAT
1	WN1 HANDWHEEL NUT BRASS (M5)	850481	5013866060977	01/01/1900	To Current	££0.50
1	WN1 HANDWHEEL NUT BRASS (M5)	850481	5013866060977	01/01/1900	To Current	££0.50
1	WN1 HANDWHEEL NUT BRASS (M5)	850481	5013866060977	01/01/1900	To Current	££0.50
1	WN2 HANDWHEEL NUT BRASS (M6)	850482	5013866060984	01/01/1900	To Current	££0.50
1	WN2 HANDWHEEL NUT BRASS (M6)	850482	5013866060984	01/01/1900	To Current	££0.50
1	WN2 HANDWHEEL NUT BRASS (M6)	850482	5013866060984	01/01/1900	To Current	££0.50
1	WN2 HANDWHEEL NUT BRASS (M6)	850482	5013866060984	01/01/1900	To Current	££0.50
1	WN14 HANDWHEEL NUT BRASS (M8)	850512	5013866061141	01/09/1999	To Current	££0.71
1	WN3 HANDWHEEL NUT BRASS (5/16 UNC)	851411	5013866063923	01/01/1990	31/08/1999	££0.71
1	WN15 HANDWHEEL NUT BRASS (M10)	850724	5013866061929	01/09/1999	To Current	££0.54
1	WN4 HANDWHEEL NUT BRASS (3/8 UNC)	851412	5013866063930	01/01/1990	31/08/1999	££0.90
1	WN4 HANDWHEEL NUT BRASS (3/8 UNC)	851412	5013866063930	01/01/1990	31/08/1999	££0.90
1	WN15 HANDWHEEL NUT BRASS (M10)	850724	5013866061929	01/09/1999	To Current	££0.54
1	WN1 HANDWHEEL NUT BRASS (M5)	850481	5013866060977	01/01/1900	To Current	££0.50
1	WN1 HANDWHEEL NUT BRASS (M5)	850481	5013866060977	01/01/1900	To Current	££0.50
1	WN1 HANDWHEEL NUT BRASS (M5)	850481	5013866060977	01/01/1900	To Current	££0.50
1	WN1 HANDWHEEL NUT BRASS (M5)	850481	5013866060977	01/01/1900	To Current	££0.50
1	WN2 HANDWHEEL NUT BRASS (M6)	850482	5013866060984	01/01/1900	To Current	££0.50
1	WN2 HANDWHEEL NUT BRASS (M6)	850482	5013866060984	01/01/1900	To Current	££0.50
1	WN2 HANDWHEEL NUT BRASS (M6)	850482	5013866060984	01/01/1900	To Current	££0.50
1	WN14 HANDWHEEL NUT BRASS (M8)	850512	5013866061141	01/09/1999	To Current	££0.71
1	WN3 HANDWHEEL NUT BRASS (5/16 UNC)	851411	5013866063923	01/01/1990	31/08/1999	££0.71
1	WN3 HANDWHEEL NUT BRASS (5/16 UNC)	851411	5013866063923	01/01/1990	31/08/1999	££0.71
1	WN14 HANDWHEEL NUT BRASS (M8)	850512	5013866061141	01/09/1999	To Current	££0.71
1	WN4 HANDWHEEL NUT BRASS (3/8	851412	5013866063930	01/01/1990	31/08/1999	££0.90

UNC)

1

2

3

W10 HANDWHEEL (RED)

RATING DISC 1068 - SIZE 3

850425

5013866060588

01/01/1900

To Current ££1.75

WN15 HANDWHEEL NUT BRASS (M10) 850724 5013866061929 01/09/1999 To Current ££0.54

WN4 HANDWHEEL NUT BRASS (3/8 851412 5013866063930 01/01/1990 31/08/1999 ££0.90 UNC)

WN15 HANDWHEEL NUT BRASS (M10) 850724 5013866061929 01/09/1999 To Current ££0.54

0110)

2 Spare Key Description Code Barcode Date To Price (£) ex VAT Date From 2 RATING DISC 1068 - SIZE 1 01/01/1900 850423 5013866060564 To Current ££0.58 2 RATING DISC 1068 - SIZE 1 850423 01/01/1900 To Current ££0.58 5013866060564 2 RATING DISC 1068 - SIZE 1 850423 5013866060564 01/01/1900 To Current ££0.58 2 RATING DISC 1068 - SIZE 1 850423 5013866060564 01/01/1900 To Current ££0.58 2 RATING DISC 1068 - SIZE 1 850423 5013866060564 01/01/1900 To Current ££0.58 2 RATING DISC 1068 - SIZE 1 850423 5013866060564 01/01/1900 To Current ££0.58 RATING DISC 1068 - SIZE 1 2 850423 5013866060564 01/01/1900 To Current ££0.58 2 RATING DISC 1068 - SIZE 2 850424 5013866060571 01/01/1900 To Current ££1.18 2 RATING DISC 1068 - SIZE 3 850425 5013866060588 01/01/1900 To Current ££1.75 2 RATING DISC 1068 - SIZE 3 850425 5013866060588 01/01/1900 To Current ££1.75 2 RATING DISC 1068 - SIZE 1 850423 5013866060564 01/01/1900 To Current ££0.58 2 RATING DISC 1068 - SIZE 1 850423 5013866060564 01/01/1900 To Current ££0.58 2 RATING DISC 1068 - SIZE 1 850423 01/01/1900 5013866060564 To Current ££0.58 2 RATING DISC 1068 - SIZE 1 850423 5013866060564 01/01/1900 To Current ££0.58 2 RATING DISC 1068 - SIZE 1 850423 5013866060564 01/01/1900 To Current ££0.58 2 RATING DISC 1068 - SIZE 1 850423 5013866060564 01/01/1900 To Current ££0.58 2 RATING DISC 1068 - SIZE 1 850423 5013866060564 01/01/1900 To Current ££0.58 2 RATING DISC 1068 - SIZE 2 850424 01/01/1900 To Current ££1.18 5013866060571 RATING DISC 1068 - SIZE 2 2 850424 01/01/1900 To Current ££1.18 5013866060571 RATING DISC 1068 - SIZE 3 2 850425 5013866060588 01/01/1900 To Current ££1.75

			3			
Spare Key	Description	Code	Barcode	Date From	Date To	Price (£) ex VAT
3	W1 HANDWHEEL (RED)	850100	5013866059513	01/01/1900	To Current	££7.04
3	W1 HANDWHEEL (RED)	850100	5013866059513	01/01/1900	To Current	££7.04
3	W1 HANDWHEEL (RED)	850100	5013866059513	01/01/1900	To Current	££7.04
3	W3 HANDWHEEL (RED)	850101	5013866059520	01/01/1900	To Current	££7.04
3	W4 HANDWHEEL (RED)	850102	5013866059537	01/01/1900	To Current	££7.04
3	W6 HANDWHEEL (RED)	850104	5013866059551	01/01/1900	To Current	££11.15
3	W7 HANDWHEEL (RED)	850105	5013866059568	01/01/1900	To Current	££11.15
3	W8 HANDWHEEL (RED)	850106	5013866059575	01/01/1900	To Current	££11.15
3	W10 HANDWHEEL (RED)	850107	5013866059582	01/01/1900	To Current	££20.87
3	W10 HANDWHEEL (RED)	850107	5013866059582	01/01/1900	To Current	££20.87
3	W1 HANDWHEEL (RED)	850100	5013866059513	01/01/1900	To Current	££7.04
3	W1 HANDWHEEL (RED)	850100	5013866059513	01/01/1900	To Current	££7.04
3	W1 HANDWHEEL (RED)	850100	5013866059513	01/01/1900	To Current	££7.04
3	W1 HANDWHEEL (RED)	850100	5013866059513	01/01/1900	To Current	££7.04
3	W3 HANDWHEEL (RED)	850101	5013866059520	01/01/1900	To Current	££7.04
3	W4 HANDWHEEL (RED)	850102	5013866059537	01/01/1900	To Current	££7.04
3	W6 HANDWHEEL (RED)	850104	5013866059551	01/01/1900	To Current	££11.15
3	W8 HANDWHEEL (RED)	850106	5013866059575	01/01/1900	To Current	££11.15
3	W8 HANDWHEEL (RED)	850106	5013866059575	01/01/1900	To Current	££11.15
3	W10 HANDWHEEL (RED)	850107	5013866059582	01/01/1900	To Current	££20.87

			7			
Spare Key	Spare Key Description		Barcode	Date From	Date To	Price (£) ex VAT
4	GN1 GLAND NUT	850310	5013866059889	01/01/1900	To Current	££1.85
4	GN11 GLAND NUT	851338	5013866063916	01/01/1900	To Current	££2.81
4	GN11 GLAND NUT	851338	5013866063916	01/01/1900	To Current	££2.81

850107 5013866059582 01/01/1900 To Current ££20.87

4	GN8 GLAND NUT	0312 5	013866059902	01/01/19	00 To Current	££3.52	
4	GN9 GLAND NUT	85	0313 5	013866059919	01/01/19	00 To Current	££3.52
4	GN10 GLAND NU	IT 85	0314 5	013866059926	01/01/19	00 To Current	££2.81
4	GN12 GLAND NU	IT 85	0315 5	013866059933	01/01/19	00 To Current	££4.22
4	GN13 GLAND NU	IT 85	1150 5	013866063893	01/01/19	00 To Current	££4.68
4	GN15 GLAND NU	IT 85	0317 5	013866059940	01/01/19	00 To Current	££4.68
4	GN23 GLAND NU	IT 85	1029 5	013866063862	01/01/19	00 To Current	££5.86
4	GN1 GLAND NUT	85	0310 5	013866059889	01/01/19	00 To Current	££1.85
4	GN1 GLAND NUT	85	0310 5	013866059889	01/01/19	00 To Current	££1.85
4	GN11 GLAND NU			013866063916	01/01/19		
4	GN11 GLAND NU			013866063916	01/01/19		££2.81
4	GN8 GLAND NUT			013866059902	01/01/19		££3.52
4	GN9 GLAND NUT			013866059919	01/01/19		££3.52
4	GN10 GLAND NU			013866059926	01/01/19		££2.81
4	GN13 GLAND NU			013866063893			
					01/01/19		
4	GN13 GLAND NU			013866063893	01/01/19		
4	GN15 GLAND NU			013866059940	01/01/19	00 To Current	££4.68
4	GN23 GLAND NU	IT 85	1029 5	013866063862	01/01/19	00 To Current	££5.86
				5			
Spare Key	Description	Barco	ode	Date From	Date To	Price (£) ex VAT	
5	G1 GLAND	50138	366065163	01/01/1900	To Current	££1.07	
5	G16 GLAND	50138	366061011	01/01/1900	To Current	££1.42	
5	G16 GLAND	50138	366061011	01/01/1900	To Current	££1.42	
5	G17 GLAND	50138	366061028	01/01/1900	To Current	££1.42	
5	G18 GLAND	50138	366057274	01/01/1900	To Current	££1.42	
5	G19 GLAND	850487	50138	366061035	01/01/1900	To Current	££1.53
5	G20 GLAND	850488	50138	366061042	01/01/1900	To Current	££1.64
5	G21 GLAND	850489	50138	366061059	01/01/1900	To Current	££1.85
5	G22 GLAND	850490	50138	366061066	01/01/1900	To Current	££2.13
5	G15 GLAND	850369	50138	366060274	01/01/1900	To Current	££2.35
5	G1 GLAND	855236	50138	366065163	01/01/1900	To Current	££1.07
5	G1 GLAND	855236			01/01/1900	To Current	££1.07
5	G16 GLAND	850485			01/01/1900	To Current	££1.42
5	G16 GLAND	850485			01/01/1900	To Current	££1.42
5	G17 GLAND	850486			01/01/1900	To Current	££1.42
5	G18 GLAND	815202			01/01/1900	To Current	££1.42
5	G19 GLAND	850487			01/01/1900	To Current	££1.53
5	G21 GLAND	850489			01/01/1900	To Current	££1.85
5	G21 GLAND	850489			01/01/1900	To Current	££1.85
5	G22 GLAND	850490		366061066	01/01/1900	To Current	££2.13
5	G15 GLAND	850369		366060274	01/01/1900	To Current	££2.35
3	GT3 GLAND	830309	30130	300000274	01/01/1900	TO Current	LLZ.55
				6			
Spare Key	Description		Code	Barcode	Date Fr		Price (£) ex VAT
6	GP2 GLAND PACI		855248	50138660652			
6	GP12 GLAND PAC		850327	50138660600			
6	GP12 GLAND PAG	CKING	850327	50138660600	21 01/01/1	900 To Currer	t ££0.90
6	GP8 GLAND PACI	KING	855241	50138660651	87 01/01/1	900 To Currer	t ££0.90
6	GP10 GLAND PAG	CKING	850325	50138660600	07 01/01/1	900 To Currer	t ££0.90
6	GP9 GLAND PACKING		855247	50138660652	00 01/01/1	900 To Currer	nt ££1.18
6	GP16 GLAND PACKING		855245	50138660651	94 01/01/1	900 To Currer	nt ££1.18
6	GP17 GLAND PACKING		850331	50138660600	69 01/01/1	900 To Currer	nt ££1.64
6	GP18 GLAND PACKING		851907	50138660639	54 01/01/1	900 To Currer	nt ££1.64
6	GP19 GLAND PAG	CKING	850332	50138660600	76 01/01/1	900 To Currer	nt ££1.85
6	GP2 GLAND PACI	KING	855248	50138660652	17 01/01/1	900 To Currer	t ££0.90
6	GP2 GLAND PACI	KING	855248	50138660652	17 01/01/1	900 To Currer	t ££0.90
6	GP12 GLAND PAG	CKING	850327	50138660600	21 01/01/1	900 To Currer	t ££0.90

6	GP12 GLAND PACKING	850327	7 5013866060021	01/01/1900	To Current	££0.90
6	GP8 GLAND PACKING	855241	5013866065187	01/01/1900	To Current	££0.90
6	GP10 GLAND PACKING	850325	5 5013866060007	01/01/1900	To Current	££0.90
6	GP9 GLAND PACKING	855247	7 5013866065200	01/01/1900	To Current	££1.18
6	GP17 GLAND PACKING	85033	5013866060069	01/01/1900	To Current	££1.64
6	GP17 GLAND PACKING	85033	5013866060069	01/01/1900	To Current	££1.64
6	GP18 GLAND PACKING	851907	7 5013866063954	01/01/1900	To Current	££1.64
6	GP19 GLAND PACKING	850332	5013866060076	01/01/1900	To Current	££1.85
			7			
Spare Key	Description	Code	Barcode	Date From	Date To	Price (£) ex VAT
7	LS6 LOCKSHIELD	855238	5013866065170	01/01/1900	To Current	££2.96
7	LS6 LOCKSHIELD	855238	5013866065170	01/01/1900	To Current	££2.96
7	LS3 LOCKSHIELD	850152	5013866059681	01/01/1900	To Current	££2.96
7	LS9 LOCKSHIELD	815201	5013866057267	01/01/1900	To Current	££4.68
7	LS13 LOCKSHIELD	850416	5013866060502	01/01/1900	To Current	££5.86
7	LS14 LOCKSHIELD	850367	5013866060250	01/01/1900	To Current	££7.04
7	LS6 LOCKSHIELD	855238	5013866065170	01/01/1900	To Current	££2.96
7	LS6 LOCKSHIELD	855238	5013866065170	01/01/1900	To Current	££2.96
7	LS3 LOCKSHIELD	850152	5013866059681	01/01/1900	To Current	££2.96
7	LS9 LOCKSHIELD	815201	5013866057267	01/01/1900	To Current	££4.68
7	LS13 LOCKSHIELD	850416	5013866060502	01/01/1900	To Current	££5.86
			8			
Spare Key	Description	Code	Barcode	Date From	Date To	Price (£) ex VAT
8	K9 LOCKSHIELD KEY	850139	5013866059650	01/01/1900	To Current	££6.12
8	K9 LOCKSHIELD KEY	850139	5013866059650	01/01/1900	To Current	££6.12
8	K2 LOCKSHIELD KEY	817020	5013866058448	01/01/1900	To Current	££6.79
8	K3 LOCKSHIELD KEY	850132	5013866059612	01/01/1900	To Current	££9.18
8	K5 LOCKSHIELD KEY	850134	5013866059629	01/01/1900	To Current	££12.18
8	K6 LOCKSHIELD KEY	850135	5013866059636	01/01/1900	To Current	££22.28
8	K9 LOCKSHIELD KEY	850139	5013866059650	01/01/1900	To Current	££6.12
8	K9 LOCKSHIELD KEY	850139	5013866059650	01/01/1900	To Current	££6.12
8	K2 LOCKSHIELD KEY	817020	5013866058448	01/01/1900	To Current	££6.79
8	K3 LOCKSHIELD KEY	850132	5013866059612	01/01/1900	To Current	££9.18
8	K5 LOCKSHIELD KEY	850134	5013866059629	01/01/1900	To Current	££12.18

Pegler Yorkshire Group Ltd, St Catherine's Ave, Doncaster, S Yorkshire, DN4 8DF
Telephone: Phone +44 (0) 844 243 4400 Fax: +44 (0) 844 243 9870 Website: www.pegleryorkshire.co.uk
Registered office: Pegler Yorkshire Group Ltd, St Catherine's Ave, Doncaster, S Yorkshire, DN4 8DF Company no: 00401507

## THE PRESSURE EQUIPMENT DIRECTIVE 97/23/EC & CE MARKING

maximum working pressure, size and rising level of hazard. The designated as SEP do not bear the CE mark nor require a fluids including steam. The categories designated are SEP (sound level of hazard varies according to the fluid being carried. Fluids mark and require a Declaration of Conformity. Valves classified having increased hazard are categorised as, I, II, III or IV. All valves engineering practice). Valves up to and including 25mm (1") are are classified as Group 1 ,dangerous fluids or Group 2, all other these new Regulations. Valves are categorised according to their maximum allowable pressure greater than 0.5 bar are covered by Declaration of Conformity. Categories I, II, III or IV carry the CE designated SEP regardless of the fluid group. Those identified as been introduced into United Kingdom law. Valves with a Pressure Equipment Regulations 1999 (SI 1999/2001) have

## from the piping chart would not be included in Category IV. CE MARKING & THE ATEX Directive 94/9/EC

valve: a) has its own potential source of ignition. b) operates in a SI2001/3766). The regulations apply to all valves where each Protective Systems (amendment) Regulations 2001 1996(31 1996/192) and amended by The Equipment and Intended for Use in Potentially Explosive Atmosphere Regulations ootentially explosive atmospheres. This has been implemented in Jnited Kingdom law by the Equipment and Protective Systems Concerning equipment and protection systems intended for use in blanking plug to the downstream end of the valve. Pegler Bali

potentially explosive atmosphere created by: ii) the presence of gases, vapours, mists released from the the presence of air/dust mixtures external to the valve.

The regulations will not apply to a valve without a potential source

of ignition, which operates in a dust free environment and the fluid being transported is cold, inert gas or non-flammable liquid. The regulations is defined as Group II category 2 and shall bear iollowing markings: ⟨Ex⟩ II 2 GD X equisite level of protection for valves not exempt from VALVE SELECTION Selection, Storage & Protection to which the valve is being installed or maintained. appropriate to the hazard presented by the nature of the process

preventative maintenance it should give years of trouble-free the fluids that they are intended to carry. Interactions between service. They must be compatible with the system design conditions. Provided it is installed correctly and receives adequate Valves must be properly selected for their intended service oressure and temperature requirements and must be suitable to

/aives snould be stored off the ground in a clean, dry, indoor area

metals in the pipe system and the valve must be considered.

appropriate and so adequate protection from damage is provided Where desiccant bags are included with the valve these should be

## assemblies, suitable protective devices may be required. When Pegler valves are fitted with pressure equipment PRESSURE/TEMPERATURE RATING

and temperature does not exceed the stated rating of the valve. If system testing will subject the valve to pressures in excess of the should also be avoided. standards is for non-shock conditions. Water hammer and impact The maximum allowable pressure in valves as specified in the valves must be installed in a piping system whose normal pressure

It may be hazardous to use these valves outside of their specified pressure for the body" to a maximum of 1.5 times the PN rating and working pressure rating, this should be within the "shell test conducted with the valve fully opened.

# pressure and temperature limitations and also when not used for

he correct application.

LOCATION/END-OF-LINE SERVICE

valve siting should be decided during the system design phase. To end of line service but we strongly recommend the fitting of a they must be adequately supported.

The 1072, 1070/125, 1065 and 1068 Gate valves are suitable for prevent imposing strain on the valve seat, pipe work and valves To ensure ease of operation, adjustment, maintenance and repair

## Globe, Check, Flanged and Lever Gate valves are not suitable for end-of-line service. INSTALLATION Health & Safety

exceeded and reduction or elimination of any potential hazards. Before starting work on any installation a risk assessment must be Protective clothing and safety equipment must be utilised as nade to consider the possibility of operational limits being

pumps (when fitted) must be turned off. The pipeline must be depressurised, drained and vented. Valves must be fully opened to ensure release of any pipeline or valve pressure. . Before installing or removing a valve the pipeline circulating

on the valve nameplate, body or data plate. These must not be The valve selected must be suitable for the required service enable them to safely lift and install Pegler valves. conditions. The pressure and temperature limitations are indicated Fitters must be trained in manual and mechanical handling to

system debris. Protective devices may need to be fitted and Valve seats, seals and internal components can be damaged by

system flushing may be required.

Any flushing fluid used to clean the pipeline must not cause any . Pegler valves must not be misused by lifting them by their hand

wheels, levers or stems.

erosive service, or for carrying fluids containing abrasive solids. conditions, fire testing, fire hazard environment, corrosive or fluids and must not be used where this could occur. Designs for this valve do not allow for decomposition of unstable There is no allowance for corrosion in the design of these valves. Pegler valves are not suitable for fatigue loading, creep

10. All Health and Safety Rules must be followed when installing wind, earthquakes and traffic.

## and maintaining valves.

valve has been selected for installation. Unpack the valve and check that the flow paths and valve threads Check the body markings and nameplate to ensure that the correc

Make sure that a gate valve is fully closed during installation. on the body. The valve will function correctly providing it is fitted so and upright". Globe valves are marked with a directional flow arrow with stem horizontal" or "Horizontal pipe work with stem vertical that the fluid transported follows the indicated flow direction. Gate valves and Globe valves may be fixed in "Vertical pipe work

operated from fully open to fully closed to test that it has been Fitting a gate valve in the open position may cause twisting and the gate and seating may not mate properly. The valve should be The valve should not be installed in horizontal pipe work with stem

following should be avoided: \*Careless handling of the valve standards and, therefore, should not be subjected to misuse. The of system debris. Pegler Valves are manufactured to exacting 'Dirt and debris entering the valve through the end ports horizontal because full closure may be impeded by an accumulation Excessive force during assembly and hand wheel operation. Valves should not be lifted using the hand wheel, lever or the stem) the valve. Closure will be confirmed when the handle can be turned To close the valve a clockwise rotation of the hand wheel will close

pipe upstream and 3 diameters downstream are suitable flow arrow on the body. The valve will function correctly providing i Horizontal and Vertical pattern check valves may be fitted in Ball valves may be fixed in any orientation, always leaving horizontal pipe work with the cap upper most and vertically with the enough space for the 90° operation of the lever handle direction. Check valves having 6 diameters of straight length of low in an upwards direction. The valve is marked with a directional titted so that the fluid transported follows the indicated flow

 Pegler valves are not designed to withstand the effects of fire, compound can lead to valve failure on the body ends. Threads be forced outwards and will not enter the valve. Over use of the valve in order to remove stresses transmitted by the pipe Any electrical component e.g. actuators, limit switches must valves and seats by the use of hand wheels or levers larger than to the joint being made. Severe damage can occur to stems should be engaged correctly when tightening the valve onto the pipe only and not in the valve threads. Surplus compound will then damage. Care should be taken to apply jointing compound to the close to reciprocating pumps, then the velocity should not exceed non uniform or pulsating flow enters the valve, e.g. the valve is pipe. The wrench should always be fitted on the body end adjacent penetration of the pipe into the valve that would otherwise cause Confirm that the pipe threading length is correct to avoid excessive hose originally supplied by the manufacturer, and by wheel keys ? metres per second. Use suitable hangers close to both ends c

## explosion proof and comply with the ATEX Directive and Standards as listed in BS EN 1127-1 clause 6.4.5.

valve. When it will go no further return the hand wheel clockwise be turned no turther. will close the valve. Closure will be confirmed when the handle car 1/2 turn. To close the valve a clockwise rotation of the hand wheel To open - an anti-clockwise rotation of the hand wheel will open the Gate Valves

cause the wedge to become tight in the valve. The valve may be become stiff to operate in these circumstances. Suitable hand open or fully closed position. Gate valves are not suitable protection should be worn when operating valves used in extreme Caution: Service applications with extremes of temperature may emperature applications. The valve should only be used in the fully

egulating and throttling service.

valve. When it will go no further return the hand wheel clockwise To open - an anti-clockwise rotation of the hand wheel will open the

suitable for regulating and throttling service. valves used in extreme temperature applications. Globe valves are Caution: Suitable hand protection should be worn when operating

operation. the flow within the pipeline and there is no external method c The Horizontal/vertical pattern check valves operate according to Check Valves

so that it is across the line of the pipe in which it is installed. Ful PB T Models have lockable handles for use in both open and opening and closing is completed when a full 90° is achieved and with the pipe run in which it is installed. To close - turn the lever 90°

ensuring the handle slot engages on to the body lug. Insert the then be rotated through 180° and refitted on to the valve spindle lifts the lever away from the body and is particularly useful when **PB EL** models are fitted with an extended spindle mechanism that screw. The T handle can then be lifted from the valve. This should key of the appropriate size can be used to remove the securing with the pipe work. To lock the valve in the open position a hexagor closed positions. In the fully open position the T handle is in line securing screw and re-tighten with the hexagon key. Re-assemble the gland ring and gland nut.

pipe insulation is being used. This version is only available with standard lever handle.

open or fully closed position. Ball valves are not suitable temperature applications. The valve should only be used in the fully Caution: Service applications with extremes of temperature may orotection should be worn when operating valves used in extreme become stiff to operate in these circumstances. Suitable hand cause the ball to become tight in the valve. The valve may be

## egulating or throttling applications. MAINTENANCE

this should be collected and/or tiltered by installation of the be used for valve maintenance work. Separate means of draining the pipe work must be provided when carrying out any appropriate protective device. maintenance to valves. Where there may be any system debris could lead to failure. The correct fitting tools and equipment should possibility of operational limits being exceeded and the potentia planned procedure of how the maintenance will be carried out. The ensuring longer term operational efficiency of the selected valve condition and any development of unforeseen conditions, which This should be implemented to include visual checks on the valve's nazards ensuing must be considered as part of this assessment Such a program would need to include a risk assessment and a \ regular maintenance program is the most efficient method o

installation and then periodically thereafter to maintain a sterr giand seal. Gland Adjustment. - The gland may need adjustment during

necessary

however, in the event of maintenance being necessary, gate and globe valves do not normally require any maintenance Gland Replacement - Under normal working conditions Pegle nspected at 3 monthly intervals to check for gland leakage. NOTE: It is recommended that within the 1st year the gland

any

lechnical Department for further information available from Sales Office.

egler recommended spares must be used.

to Pegler

PB LEVER HANDLE To open - turn the lever 90° so that it is in line Before starting work, de-pressurise the system, turn off following procedure should be followed:

ring. Using a suitable tool, lift out the existing packing nut, nameplate and hand wheel. Remove the gland nut must be taken not to damage the valve stem. sure the stem and stuffing box are clean & free from debris. Care circulating pumps. Slacken the hand wheel nut and remove the

and push down firmly. Fit a replacement Pegler packing gland into the stuffing box

tightness should be made, further adjust the gland nut as Tighten the gland nut and confirm stem resistance while operating the valve. Once line pressure is re-established a check for leak Tighten the gland nut and confirm stem resistance while necessary to achieve a satisfactory seal. Re-attach the handwheel, nameplate and nut. required

the Data.

Reference Material: Pegler Valves Package Brochure, Pegler commissioning the system as this would help extend the valve life.

NB. Permanent removal of the gland nut and /or Ball valves and Check valves are generally NOT suitable for Plate will invalidate the CE compliance of this valve. Pegler

only permissible if: a) no hazarous explosive atmosphere is permitted in Zones 1 & 21. Tools causing showers of sparks are e.g. screwdriver, spanner, impact screwdriver or "shower of Explosion prevention and protection. Tools are either "single spark" be subject to a "permit to work" system present. The use of tools on equipment in Zones 1 and present. b) dust deposits have been removed and no dust cloud is sparks" e.g. sawing or grinding. Only steel "single spark" protective level defined as Group II catergory 2 will operate in Zone According to valve type, gland packing and valve discs may be replaced. Valves within the scope of the ATEX Directive with a 1029 Renewable Valve Disc Replacement. (gases/vapours) or Zone 21 (dust) designated in BS1127-1 21 should tools are

Before starting work de-pressuries the system, turn off any circulating pumps, and ensure the valve is empty of fluid. Using a suitable wrench remove the complete bonnet assembly from the valve. Care should be taken to ensure the pipework is held failure. Slacken and remove disc nut and disc. securely during this process so that there is no distortion to the valve threads. Any damage to the threads could lead to valve ık.sales@pegler.co.uk

Re-assemble the bonnet in to the valve body, checking for damage. Ensure the valve bonnet is joined securely to body and will not leak. type as appropriate. Re-attach a replacement disc and disc nut. The valve disc can be replaced with an equivalent size disc and Assess damage to valve seat replacing the valve if export@pegler.co.uk

and gland and make and cleaning of the pipe work installation should take place when and the valve which need to be considered. Appropriate flushing pressure and temperature requirements the life expectancy of the considering the compatibility of the system design and the give years of trouble-free service provided it is installed correctly There may also be interactions between metals in the pipe system the valve performance as this could lead to premature valve failure. nature of the fluid being carried through the valve could also affect valves can be adversely affected and valve failure may occur. The When a valve is properly selected for its service conditions it should receives adequate preventative maintenance. By

PRODUCT LIFE SPAN

Yorkshire DN4 8DF England www.pegler.co.uk Pegler Limited, St Catherine's Avenue, Doncaster,

Head Office: PRIOR NOTICE


Western Tel: 0870 1200283 Fax: 01302 560109 Southern Tel: 0870 1200282 Fax: 01302 560458 Northern Tel: 0870 1200281 Fax: 01302 560108

Tel: 44 (0) 1302 855656 Fax: 44 (0) 1302 730513



QUALITY • RELIABILITY • INNOVATION

Installation, Operating & Maintenance Instructions are N.B. The 1029 Globe valves have non-metallic PTFE valve discs.



## **Installation, Operating & Maintenance Instructions Pressure Equipment Directive**

**Engineers Valves** 

PED 97/23/EC Compliant A Watertight Guarantee Of Quality

				(
PB500 RED	PB 700	Pro		Č
	-	Product		(
		~		H
ς.	Ę	St		
-		Steam		Š
		_		
<	۲	Water		Ì
		¥		Ċ
<	<	<u>o</u>	VALVE SUITABILITY	:
		=	Æ	Ċ
•	•		SU	(
*	*	₽i	ΆΒ	ţ
	_			(
×	<b>\$</b>	Gas	~	(
		-ω		
×	5	റംപ		
	*	Gas Combustible		8
	_			-
×	<b>?</b>	Gas Corrosive		2
		è		(
×	×	ွှင့		t
		Gas Oxygen		

PB 100

1070/125

۲

۲

1072

۲

۲ < ۲

۲

X X ×

۲

**1068** ᇙ

۲ X PB300 RED/BLUE PB500 YELLOW

ς.

۲

۲

Ş

Ş

Ş

Ş

×

Thread Depths (mm)

PB300 YELLOW

۲ ۲

۲ ۲

Ş Ž

Ş

X

×

×

X ×

<

<

Ş

۲

5

J		- 011	COK VOI			dione	Valvos			_ "	utc #411	-		_	_				_	_	4
	1064	1063	1062	1060A	1039	1031	1029	GM63	63	P81 M	1070/125	1072	1068	1065	PB100	PB300 YELLOW	PB300 RED/BLUE	PB500 YELLOW	PB500 RED	PB700	Product
	•						7.5				11.4							11.5	11.5	11.5	1/4"
	10.3	10.3					7.9				11.4							11.9	11.9	11.9	3/8
	12.8	12.8	15.9	15.0	9.9	9.9	9.9				15.0	15.0	15.0	12.7	12.7			15.4	15.4	15.4	1/2"
	14.2	14.2	16.7	16.3	11.1	11.1	11.1				16.3	16.3	16.3	14.0	14.0			16.7	16.7	16.7	3/4"
	15.0	15.0	19.0	19.1	12.3	12.3	12.3				19.1	19.1	19.1	16.1	16.2			19.4	19.4	19.4	<u>-</u>
	15.2	15.2		21.4	14.3	14.3	14.3				21.4	21.4	21.4	18.5	18.5			21.7	21.7	21.7	1.1/4"
	16.4	16.4		21.4	14.3	14.3	14.3				21.4	21.4	21.4	18.5	18.5			21.4	21.4	21.4	1.1/2
	17.2	17.2		25.7	18.2	18.2	18.2				25.7	25.7	25.7	22.8	22.8			26.0	26.0	26.0	2
	19.8	19.8		25.0			19.8				30.2		30.2				,	30.5	30.5	30.5	2.1/2

33.3

39.3

P81M

1070/12 1072 33.3

39.3

1068 1065 33.5 33.5 33.5

39.5 39.5

PB300 PB500

PB100 PB300 ယ္

39.5

PB700

PB500 RED Product

1832 2

**1**64 1063 1062 1060A <u>1039</u>

X X

۲

Ž Ž

×

<

5

<

<

X X X ×

X X X ×

< ۲ ۲

<

۲

<

۲ ۲ ۲ ۲

Ş

Ž

Ž

× × × × X X X

× × × × X X X

× × × × X X X

Pressure limited to 10 bar for Air & Gas applications. The Pressure limited to 5 bar for Air applications.

۲

X × X X < < ۲ ۲

× ×

X × × × X X X ×

× × × × × × × × × × × ×

833GM, GMLS

1832 1064

,

,

. .

.

•

,

26.0

26.0

26.6 26.6

1064 1063 33.0

33.0

1062

1060A 1039 1031 22.6

1029

GM63 63

× × 1029 GM63

× ×

۲

## **OPERATIONAL LIMITS**

PED Categorisation Table

Non- Shock Pressure @ Temp. Range Non- Shock Pressure @ Max. Range 40 Bar - 10°C to 110°C 10 Bar at 180°C

25 Bar - 10°C to 100°C

16.5 Bar at 150°C

**₽** 25

=						=	=	G.	6	22	=	=	=	=	교	ъ	Ball Valves							
Cocks		Ch	eck Val	ves		Globe	Valves			G	ate Valv	es					Ball V	alves						
10 Bar at 120°C	90°C	90°C	10.5 Bar at 186°C	10.5 Bar at 186°C	14 Bar at 198°C	14 Bar at 198°C	14 Bar at 198°C	5 Bar at 120°C	5 Bar at 120°C	9 Bar at 180°C	9 Bar at 180°C	14 Bar at 198°C	9 Bar at 180°C	17.5 Bar at 93°C	4 Bar at 120°C	5 Bar at 120°C	5 bar at 120°C	16.5 Bar at 150°C						
10 Bar - 0°C to 120°C	0°C to 90°C	0°C to 90°C	25 Bar - 10°C to 100°C	25 Bar - 10°C to 100°C	32 Bar - 10°C to 100°C	32 Bar - 10°C to 100°C	32 Bar - 10°C to 100°C	16 Bar - 10°C to 30°C	16 Bar - 10°C to 30°C	20 Bar - 10°C to 100°C	20 Bar - 10°C to 100°C	32 Bar - 10°C to 100°C	20 Bar - 10°C to 100°C	17.5 Bar - 0°C to 25°C	25 Bar - 10°C to 100°C	16 Bar - 10°C to 30°C	16 Bar - 10°C to 30°C	25 Bar - 10°C to 100°C						
10	8 - 12	8 - 12	25	25	32	32	32*	16	16	16	20	32	20	17.5	25	16*	16	25*						
											25					YELLOW	RED/BLUE	YELLOW						

<sup>10</sup> bar for Gas

833GM, GM LS

ರ

20 Bar - 10°C to 100°C

13 Bar at 120°C

Category 1 and Category 2 carry the CE mark

	Cocks	Check Valves				Globe Valves		Gate Valves							Ball Valves							
833GM, GM LS	1832	1064	1063	1062	1060A	1039	1031	1029	GM63	63	P81M	1070/125	1072	1068	1065	PB 100	PB300 YELLOW	PB300 RED/BLUE	PB500 YELLOW	PB500 RED	PB700	Product
								S.E.P				S.E.P							S.E.P	S.E.P	S.E.P	1/4"
								S.E.P				S.E.P							S.E.P	S.E.P	S.E.P	3/8
S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	1/2"
	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	3/4"
	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	<u>-</u>
		S.E.P	S.E.P		S.E.P	S.E.P	S.E.P	Cat 1	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P		S.E.P	Cat 1	S.E.P	Cat 1	1.1/4"
		S.E.P	S.E.P		S.E.P	S.E.P	S.E.P	Cat 1	S.E.P		S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P		S.E.P	Cat 1	S.E.P	Cat 1	1.1/2"
		S.E.P	S.E.P		S.E.P	S.E.P	S.E.P	Cat 1	S.E.P		S.E.P	S.E.P	S.E.P	S.E.P	S.E.P	S.E.P		S.E.P	Cat 1	S.E.P	Cat 1	2
		S.E.P	S.E.P		S.E.P			Cat 2				S.E.P		S.E.P					Cat 1	S.E.P	Cat 1	2.1/2
		S.E.P	S.E.P		S.E.P			Cat 2				S.E.P		S.E.P					Cat 1	S.E.P	Cat 1	ယ္ခ
		S.E.P	S.E.P		Cat 2							S.E.P		S.E.P					Cat 1	S.E.P	Cat 1	4